



LS-937K

PARTS LIST

ITEM	PARTS NO	PARTS NAME	Q'TY	ITEM	PARTS NO	PARTS NAME	Q'TY	ITEM	PARTS NO	PARTS NAME	Q'TY
01	926-004	Washer	1	36	959-092	Water Seal	2	71	926-5022A	Overflow Hose	1
02	926-003	Cowl	1	37	959-095	Seat, Water Seal	2	72	960-025	Overflow Spring	1
03	926-002	Hood	1	38	959-096B	O-Ring 25*2	2	73	959-054	Plug Hole	1
04	926-005	Seal	1	39	959-093	Water Seal	2	74	959-052	Plunger	1
05	926-006	Sieve Filling	1	40	959-051	Cylinder Bushing	2	75	959-053	Joint	1
06	936-001A	Water Tank	1	41	959-087	Water Seal Box	2	76	959-206	Screw M6*50L	4
07	926-009	Back Belt	1	42	959-045	Tube, Screw Bush	2	77	959-203	Screw M5*50L	4
08	927-012R	Bracket	1	43	959-088	Water Seal Box (Hole)	2	78	959-2111	Screw M6*16L	5
09	927-013R	Bracket	1	44	959-201A	Screw M5*28L	10	79	959-2151	Anti-Loose Nut M6	5
10	937-019	Engine Seat	1	45	959-041	Valve Seat	2	80	959-2121	Screw M6*20L	2
11	926-018	Shake-proof Plug	3	46	959-040	O-Ring 22*2	4	81	959-2101	Screw M6*12L	2
12	926-011R	Chair	1	47	959-042	Stopper	2	82	959-010	Fixed Nut M6*17.5L	2
13	926-015	Way	1	48	959-044	Spring Valve	2	83	959-010A	O-Ring10*2.5	2
14	926-008A	Ring, Plug Drain	1	49	959-094	O-Ring 30*2.4	2	84	959-010B	Flange Nut M6	2
15	926-007A	Water Cock	1	50	959-050N	Discharge Metal	1	85	959-2131	Screw M6*25L	2
16	27-076	O-Ring 16*2 viton	2	51	959-049N	Overflow Metal	1	86	959-213A1	Screw M6*30L	2
17	926-025B	Pad Cushion	1	52	959-042A	Washer	2	87	959-205	Screw M6*22L	2
18	959-224	Washer	4	53	959-046A	O-Ring 14*2	2	88	959-204	Screw M6*16L	2
19	959-2191	Screw 1/4**3/4"	8	54	959-077	O-Ring 10*3	1	89	926-016K	Earth Cable	1
20	926-016	Stop Switch	1	55	959-059	Seat, Overflow Valve	1	90	926-068R	High Pressure Hose	1
21	926-014B	Lever Seat	1	56	959-058	O-Ring 13*2.5	1	91	926-085	Twirl Preventer 8.5mm	1
22	926-014A	Lever	1	57	959-060	3/8" Stainless Ball	1	92	926-069A	Handle	1
23	926-039A	Clutch Drive 54mm	1	58	959-061	Under Metal	1	93	926-086	Ball Spray Rod Cock 8.5mm	1
24	959-026	Gear Box	1	59	959-062	Spring	1	94	926-079A	Spark Tools	1
25	959-035A	Bearing(6000)	3	60	959-065	Regulating Screw	1	95	936-088	Mixed Tank	1
26	959-031	Shaft Of Smaller Gear	1	61	959-065A	O-Ring 7.3*2.4	1	96	926-070C	Sprayer Gun Rod	1
27	959-028	Shaft Of Bigger Gear	1	62	959-057N	Overflow Body	1	97	926-089	Resin Nozzle	1
28	959-034A	Bearing(6001)	1	63	959-067	Fly Nut	1	98	926-024E	Clamp, Hose 16.5mm	1
29	959-027	Gear Box Cover	1	64	959-066	Adjusting Pan	1	99	959-208	Screw M5*12L	2
30	926-021U	Screw	1	65	959-217	Washer M6*16	18	100	959-209	Washer M5	2
31	959-037	Shaft, Eccentric	1	66	959-2161	Spring Washer M6	12	101	LU-1101103	Adaptor	2
32	959-033A	Bearing(6004)	1	67	959-2141	Nut M6	8	102	926-086A	O-Ring	2
33	959-046N	Cylinder	1	68	926-024C	Clamp, Hose 14mm	2	103	926-024H	Clamp, Hose 18mm	1
34	959-047	Cover Dust	1	69	926-5024A	Suction Hose	1	104	926-009D	snap	1
35	959-048	Bush Plunger	2	70	959-023A	Suction Spring	1	105	3WBD20-005	Cowl	2